




INSTALLATION MANUAL









sales@nedlandsgroup.com.au



Safety Instructions

- Switch off before installation.
- Licensed electrician for installation only.
 Non-dimmable version, not for use with light dimmers.
- Dimmable Version, if it is triac dim, for use with triac dimmer.
- Product modification is not valid for warranty.

Production Specification


IP Rating:
Voltage:
Wattage:
Ambient Temperature:
Storage Conditions:

IP20 / IP65 See details on package See details on package -20℃~+45℃ -20℃~+65℃

How to Install

- Subject to Figure 1 & Table 1 for installation place and conditions
- Follow Figure 2 install steps to finish installation

RISK OF FIRE - Required clearance from structural members and building elements SCB=25mm HCB=25mm




Tab

A-gap above the top of fitting	25mm
B-side gap to structural membrane	25mm
C-the gap to thermal insulation	25mm

A How to Install (continued)

Fig.2



Warning:

Input wire diameter ≥0.75mm²;

Product modification and improper installation are not valid for warranty!